



# WR485

The ZKTeco WR485 interface converter allows you to convert the signal from 1 Wiegand reader to the RS485 standard, allowing you to use most standard Wiegand compatible readers with the ZKTeco C2-260 controller.

The C2-260 controller supports up to 4 of these adapters. Each of the adapters can be assigned its own address on the RS485 bus.

